



Replacement Parts

Table with columns: Stock #, Description, Quantity. Lists various replacement parts like bearings, filters, gears, and suspension components.

Stock # Description

Table with columns: Stock #, Description, Quantity. Lists various replacement parts like pipe mounts, radio boxes, rods, screws, and shock absorbers.

To order replacement parts or to send your model in for repairs covered under warranty, you should send your model to DuraTrax's authorized U.S. repair facility:

Hobby Services
1610 Interstate Drive
Champaign, Illinois 61822
Attn. Service Department

Phone: (217) 398-0007 9:00 A.M. - 5:00 P.M. Central Time M-F
E-Mail: hobbysservices@hobbico.com

ST indicates Stress-Tech™ part


Optional Parts

Table with columns: Stock #, Description, Quantity. Lists optional parts like bearing sets, fuel filters, clutches, and differential gears.

Stock # Description

Table with columns: Stock #, Description, Quantity. Lists optional parts like suspension arms, tires, wheels, and glow plugs.

VELOCITY .17 EXPLODED VIEW & PARTS LIST



Replacement Parts

Table with columns: Stock #, Description, Quantity. Lists replacement parts for the engine and chassis, including bearings, carburetors, and gears.

Table with columns: Stock #, Description, Quantity. Lists replacement parts for the chassis, including suspension, wheels, and glow plugs.

DURATRAX

OVERDRIVE ST

