


Heli-Max[®]

NOVUS[™] CP

Click part numbers for more information



Heli-Max™ Novus CP Parts List

1. HMXE8326 Main Rotor Blades Novus CP
2. HMXE8552 FlyBar Novus CP
3. HMXE8553 Main Blade Grips Novus CP
4. HMXE8554 Flybar Bell Mixer Ball Carrier Novus CP
5. HMXE8555 Complete Linkage Set Novus CP
6. HMXE8556 Flybar Paddle Mounts Novus CP
7. HMXE8557 Flybar Paddles Novus CP
8. HMXE8558 Swashplate Assembly Novus CP
9. HMXE8559 Flybar Pivot Assembly Novus CP
10. HMXE8560 Head Block Assembly Novus CP
11. HMXE8561 Main Shaft Novus CP
12. HMXE7948 Main Frame Assembly Novus CP
13. HMXE8562 Feathering Spindle Novus CP
14. HMXE8563 Bell Hiller Mixing Arms Novus CP
15. HMXE7953 Servo Mount Novus CP
16. HMXE8034 Main Drive Gear Novus CP
17. HMXE7949 Battery Frame Mount Novus CP
18. HMXE8436 Tail Boom Novus CP
19. HMXE7954 Landing Gear Novus CP
20. HMXE8437 Tail Bevel Drive Gear Novus CP
21. HMXE8438 Tail Rotor Shaft Novus CP
22. HMXE7396 Printed Canopy Novus CP
23. HMXE8439 Tail Motor Mount Novus CP
24. HMXE9538 Tail Motor Wire Novus CP
25. HMXE8440 Tail Rotor Blade Novus CP
26. HMXE7331 Complete Screw Set Novus CP
27. HMXE8831 Complete Ball Bearing Set Novus CP
28. HMXG8011 Main Drive Motor Novus CP
29. HMXG8012 Tail Drive Motor Novus CP
30. HMXM2024 Servos 3g (3) Novus CP
31. HMXM2025 3 in 1 E-Board Novus CP
32. HMXJ2026 6 Channel Transmitter Novus CP
33. GPMP0408 1S LiPo 400 mAh Battery Novus CX/FP/CP