


Heli-Max



Click part numbers for more information



Key No.	Part No.	Part Name
1	HMXE2175	Rotor Blades 1SQ (2 black and 2 orange)
2	HMXE2176	1SQ Canopy
3	HMXE2177	Motor Boom Set (includes two assemblies for Right Front and Left Rear) Clockwise rotation
4	HMXE2178	Motor Boom Set (includes two assemblies for Left Front and Right Rear) Counter-clockwise rotation
5	HMXE2179	Frame Battery Holder
6	HMXE2180	Control Board Dampeners
7	HMXM2041	TAGS 3-1 Control Board 1SQ
8	HMXP1009	250mAh 1S LiPo Battery
9	HMXE2181	Screw Set 1SQ
10	HMXE2182	Motor Covers 1SQ (2 pieces)
11	HMXE2183	Foot Pads 1SQ (4 pieces)
	HMXJ2024	410 SLT Transmitter
	HMXP2023	USB Charger 1SQ