

Heli-Max®



Click part numbers for more information



Key	Part No.	Description
1	HMXE2211	Canopy White/Black
2	HMXE2210	Rotor Blades
3	HMXE2212	LED Motor Boom Set RF Clockwise
4	HMXE2213	LED Motor Boom Set LR Clockwise
5	HMXE2214	LED Motor Boom Set LF Counter
6	HMXE2215	LED Motor Boom Set RR Counter
7	HMXE2180	Control Board Dampners
8	HMZX0001	Vcam Vid/Pic Camera
9	HMXE2217	Screw Set
10	HMXE2179	Frame Battery Mount
11	HMXP1009	250mAh LiPo Battery
12	HMXM2052	TAGS-FX Control Board
13	HMXE2183	Foot Pads
	HMXJ2000	1SQ V-Cam Transmitter SLT
	HMXP2023	USB Charger
	HMZX0002	USB microSD Card Reader
	HMXE2184	Motor Cover

