



EXPAND PROGRAMMING OPTIONS WITH YOUR PC!

Install MS Connect between your MS Series ESC and PC, and you can tap into tuning options you can't do manually.

Setup and adjustments are fast and easy. Graphics simplify navigation, allowing you to select and open one of four menus. Settings within each menu are clearly identified and equipped with a slider switch. Click and drag the cursor to the setting you want, and confirm it on the settings display below. There's also a firmware update tab, so you can download updates and keep your ESC's competitive edge! For sophisticated results and simple, step-by-step programming, it's MS Connect.



MS CONNECT PROGRAMMING IS SIMPLICITY ITSELF.

Start at: Home Screen

All four menus are identified by an icon and one-word identifier. Position the cursor and click on the one you want



Settings

- 1. Low-Voltage Cutoff
- 2.Thermal Protection on/off
- 3. Motor Direction forward/reverse
- 4. Drive Mode 3 choices: FWD/REV, FWD/BRK & FWD/BRK/ REV DELAY
- Neutral Width —
 adjusts trigger travel
 between: neutral
 & brake; neutral &
 throttle



Throttle

- 1. Start Power/ Throttle Punch
- 2. Throttle Curve
- 3. Current Limiter
- 4. Coast



Timing

- 1. Boost
- 2.Turbo



Brakes

- 1. Drag Brake
- 2. Brake Strength



Includes USB adapter and cable. For PC use only. Internet connection required for firmware updates.