

# Heli-MAX<sup>®</sup> 1Si<sup>™</sup> Replacement Parts List

Click part numbers for more information

<b>Key</b>	<b>Part No.</b>	<b>Description</b>
------------	-----------------	--------------------

01	HMXE2203	Blade Guard (4)
02	HMXE2202	Rotor Blades Black / White
03	HMXE2244	Body / Frame Gray
04	HMXM2053	TAGS-FX Controller Board
05	HMXE2241	Motor/LED Right Front CCW 1Si
06	HMXE2240	Motor/LED Left Front CW 1Si
07	HMXE2243	Motor/LED Right Rear CW 1Si
08	HMXE2242	Motor/LED Left Rear CCW 1Si
09	HMXE2180	Control Board Dampeners
10	HMXE2245	Receiver Mount
11	HMXP1015	LiPo 1S 3.7V 350 mAh
12	HMXZ0001	Video / Picture Camera
13	HMXE7339	Screw Set
14	HMXE2246	Landing Pads (4)
	HMXJ2029	TX465 Transmitter SLT
	HMXP2023	USB Charger
	HMXZ0002	USB Micro SD Reader